



Particle Board Screw Countersunk Zinc

3g

| Code | Length | Phillips | Pozi |
|--------------------------------|--------|----------|------|
| Pack Qty (if available) | | | |
| C0? 0312ZP | 1/2 | 2000 | |
| C0? 0316ZP | 5/8 | 2000 | |
| Driver Bit # 1 | | | |



4g

| Code | Length | Phillips | Pozi |
|--------------------------------|--------|----------|------|
| Pack Qty (if available) | | | |
| C0? 0412ZP | 1/2 | 2000 | 2000 |
| C0? 0416ZP | 5/8 | 1000 | 1000 |
| C0? 0420ZP | 3/4 | 1000 | 1000 |
| C0? 0425ZP | 1" | 1000 | 1000 |
| Driver Bit # 1 | | | |



Replace ? With a 5 = Phillips or 6 = Pozi

5g

| Code | Length | Phillips | Pozi |
|--------------------------------|--------|----------|------|
| Pack Qty (if available) | | | |
| C0? 0512ZP | 1/2 | 2000 | 2000 |
| C0? 0516ZP | 5/8 | 1000 | 1000 |
| C0? 0520ZP | 3/4 | 1000 | 1000 |
| C0? 0525ZP | 1" | 1000 | 1000 |
| Driver Bit # 2 | | | |

Replace ? With a 5 = Phillips or 6 = Pozi

6g

| Code | Length | Phillips | Pozi |
|--------------------------------|--------|----------|------|
| Pack Qty (if available) | | | |
| C0? 0612ZP | 1/2 | 1000 | 1000 |
| C0? 0616ZP | 5/8 | 1000 | 1000 |
| C0? 0620ZP | 3/4 | 1000 | 1000 |
| C0? 0625ZP | 1" | 1000 | 1000 |
| C0? 0632ZP | 1-1/4" | 1000 | 1000 |
| C0? 0635ZP | 1-3/8" | 1000 | |
| C0? 0638ZP | 1-1/2" | 1000 | 1000 |
| Driver Bit # 2 | | | |

Replace ? With a 5 = Phillips or 6 = Pozi



Particle Board Screw Countersunk Zinc

8g

| Code | Length | Phillips | Pozi |
|--------------------------------|--------|----------|------|
| Pack Qty (if available) | | | |
| C0? 0812ZP | 1/2 | 1000 | 1000 |
| C0? 0816ZP | 5/8 | 1000 | 1000 |
| C0? 0820ZP | 3/4 | 1000 | 1000 |
| C0? 0825ZP | 1" | 1000 | 1000 |
| C0? 0828ZP | 1-1/8" | 1000 | 1000 |
| C0? 0832ZP | 1-1/4" | 1000 | 1000 |
| C0? 0835ZP | 1-3/8" | 1000 | 1000 |
| C0? 0838ZP | 1-1/2" | 1000 | 1000 |
| C0? 0841P | 1-5/8" | 1000 | |
| C0? 0845ZP | 1-3/4" | 1000 | 1000 |
| C0? 0850ZP | 2" | 500 | 500 |
| C0? 0853ZP | 2-1/8" | 500 | 500 |
| C0? 0860ZP | 2-3/8" | 500 | 500 |



Driver Bit # 2

Replace ? With a 5 = Phillips or 6 = Pozi

10g

| Code | Length | Phillips | Pozi |
|--------------------------------|--------|----------|------|
| Pack Qty (if available) | | | |
| C0? 1020ZP | 3/4 | 1000 | 1000 |
| C0? 1025ZP | 1" | 1000 | 1000 |
| C0? 1032ZP | 1-1/4" | 1000 | 1000 |
| C0? 1038ZP | 1-1/2" | 1000 | 1000 |
| C0? 1041ZP | 1-5/8" | 1000 | 1000 |
| C0? 1045ZP | 1-3/4" | 1000 | 1000 |
| C0? 1050ZP | 2" | 1000 | 1000 |
| C0? 1053ZP | 2-1/8" | 1000 | 1000 |
| C0? 1060ZP | 2-3/8" | 1000 | |
| C0? 1063ZP | 2-1/2" | 1000 | 1000 |
| C0? 1070ZP | 70mm | 500 | |
| C0? 1075ZP | 75mm | 500 | 500 |
| C0? 1080ZP | 80mm | 200 | |
| C0? 1085ZP | 85mm | 200 | |
| C0? 1090ZP | 90mm | 200 | |

Driver Bit # 2

Replace ? With a 5 = Phillips or 6 = Pozi